

## Dimensions

**Battery Cover** 



## Installation



Using the fixings provided secure the backplate to the wall at 2.5 metres above the floor. To obtain optimum performance do not site the unit close to air extraction.